



K RAIN®

RFS612™

Outdoor Irrigation Controller



STATION MODELS – Available in 6, 9 or 12 stations
INDOOR & OUTDOOR MODELS



Instruction Manual



CONTENTS

Introduction	1	Pump Start Relay Connection	24
Glossary	2	Single phase pump installation	24
Key Features	3	Master valve installation	25
Programming Instructions		Power supply connections	25
Introduction	4	Station (valve) installation	26
Set automatic program	4	Pump protection (system test)	27
Programming example	5	Fault Finding Guide	28-29
Spare watering planner	6	Electrical Characteristics	30
General tips for easy programming	7	Electrical outputs	30
Programming		Servicing the controller	31
Set current time & correct day	8	Spare watering planners	32-33
Set calendar	8	Guarantee	34
Set start times	9		
Set watering days	10-11		
Set station run times	11-12		
Manual Operations			
Run a single station	13		
Run a system test	13-14		
Run a program	14-15		
Stop watering	16		
Stacking start times	16		
Automatic back up	16		
Other Features			
Wireless rain gauge interface	17-19		
Setting individual stations & rain delay	20		
STOP all watering	21		
Water budgeting & seasonal adjustment	21		
Installation Instructions			
Mounting the controller	22		
Electrical hook-up	22		
Field wiring connections	22-23		
Terminal block layout	23		



INTRODUCTION

RPS612 is available in 6, 9 and 12 station configurations. Designed to cover a wide range of applications from residential and commercial turf, to light agriculture, and professional nursery.

This controller has a possible 3 separate programs with up to 12 starts per day. The controller has a 7 day watering schedule with individual day selection per program or a 365 calendar for odd/even day watering or selectable interval watering schedules from every day to every 15th day. Individual stations can be allocated to one or all programs and can have a run time of 1 minute to 12 hours 59 minutes or 25 hours if the water budget is set to 200%.

K-Rain has always been concerned with sustainable water usage. The controller has many water saving features that can be used to maintain the highest standard of plant quality with the least amount of water consumption. The integrated budget facility allows global changes of run times without affecting programmed run times. This allows for decreasing total water consumption on days of minimal evaporation.



GLOSSARY

LARGE HIGH CONTRAST LCD

Displays all programming information.

LARGE SELECTION DIAL

Navigates through all programming information.

LARGE MENU BUTTONS

Easy operation with fast scroll feature for entry and review.

QUICK PROGRAM SELECTION KEY

The "P" key allows faster program entry and review.



FRONT MOUNTED SENSOR SWITCH
ON/OFF switch for easy access to override

TERMINAL COVER
Easy to remove for easy access.

INTERFACE DECAL



KEY FEATURES

- 6, 9 & 12 station models.
 - Key lockable housing is suitable for outdoor or indoor installation.
 - 3 programs, each of which has 4 start times. Maximum of 12 start times per day.
 - Station run times from 1 minute to 12 hours & 59 minutes.
 - Selectable watering options:
 - Individual 7 day selection.
 - Odd or Even day selection.
 - Interval watering day selection from every day to every 15th day.
 - Watering budgeting feature allows quick adjustment of the station run times by percentage, from 10% to 200%.
 - Wireless rain gauge input will turn off all stations or selected stations during wet periods, if a K-Rain rain gauge is installed.
 - Permanent memory feature will retain automatic programs during power failures.
 - Standard 9 volt block alkaline battery can be used to program the controller remotely and to maintain the clock.
 - Manual functions:
 - Run a program or group of programs once.
 - Run a single station.
 - Run a test cycle for all stations.
 - “OFF” position, stops a watering cycle or to stop automatic programs during winter.
 - Pump or master valve input is standard.
- 
- 



PROGRAMMING INSTRUCTIONS

INTRODUCTION

This controller has been designed with 3 separate programs to allow different landscape areas to have their own individual watering schedules.

A program is a method of grouping stations (valves) with similar watering requirements to water on the same days. These stations will water in sequential order and on the days selected.

- **Group the stations** (valves) which are watering similar landscape areas together.
Examples: Turf, flower beds, gardens. These different groups may require individual watering schedules, or programs
- **Plan your watering schedule** completing the planner supplied at the back of this book.
- **Set the current time and correct day** of the week. If odd or even day watering is going to be used, make sure the current year, month and day of the month is correct.



HINT: To select a different program use the button marked **P**. Each press will move to the next program number. This is handy for quick reviewing of previously entered information without losing your place in the programming cycle.



SET AUTOMATIC PROGRAM

- Set the automatic program for each group of stations (valves) by completing the following three steps:

1. Set start times

This sets the time when the watering schedule is to commence.

Note: For each start time, all the stations (valves) selected for the program will come on in sequential order. If two start times are set, the stations (valves) will come on twice.

2. Set Watering Days

These are the selected days when the automatic system will be active.

3. Set Station Run Times

This sets the watering duration required for each station (valve).

PROGRAMMING INSTRUCTIONS

PROGRAMMING EXAMPLE

A typical example of a 9 station system is outlined below as a guide to assist you when planning your watering schedule. In this example all 3 programs are used. The lawn areas are using gear drive sprinklers, the vegetable garden is using drip and the flower beds & pots are being watered with micro sprays.



VALVE NUMBER																			
1	Front lawn				5	Back lawn				9	Vegetables								
2	Front lawn				6	Back lawn				10									
3	Front lawn				7	Flower bed				11									
4	Flower bed				8	Pots in pergola				12									
PROGRAM										PROGRAM									
	START TIME	WATERING INTERVAL	STATION	RUN TIME (minutes)	START TIME	WATERING INTERVAL	STATION	RUN TIME (minutes)	START TIME		WATERING INTERVAL	STATION	RUN TIME (minutes)						
1	Start Time 1: 6:00am	MONDAY FRIDAY	1	20	3	Start Time 1: 5:00am	Every Second Day	1		Notes:									
	Start Time 2:		2	20				2											
	Start Time 3:		3	20				3											
	Start Time 4:		4					4											
			5	20				5											
			6	20				6											
			7					7											
			8					8											
			9					9	45										
			10					10											
			11					11											
			12					12											
2	Start Time 1: 8:00pm	WEDNESDAY SUNDAY	1																
	Start Time 2:		2																
			3																
			4	10															
			5																
			6																
			7	10															
			8	10															
			9																
			10																
	11																		
	12																		

PROGRAMMING

This controller has been designed for quick intuitive programming. Remember these simple tips for hassle free programming.

1. Complete the spare watering planner at the back of this book.
2. When setting, one push of the button will increment one unit.
3. Holding one button down will fast scroll through units.
4. During the programming, only flashing units are able to be set.
5. Adjust flashing units using the  or  buttons.
6. Pressing  will scroll forward through the settings in an orderly sequence.
7. Pressing  will scroll back to previous settings and setting can be changed.

The large dial is the primary device for selecting an operation. Rotate the dial to the function you wish to alter or review.



The **P** is used to select different programs. Each push on this button will increment one program number. Once you have selected the primary function and program you wish to alter, you can then use the  or  to change that function's value. Only display elements that are flashing can be altered with the   keys. Use the   to scroll through other values within the function that can be altered.



PROGRAMMING

Set current time & correct day

Turn the dial to “Set Clock/Calendar” position.

The hour will be flashing. Use the  or  to adjust.

NOTE: AM/PM must be set correctly.

Press  button and the “minutes” will flash. Use  or  to adjust the minutes.

Press  and the “day of the week” will flash. Use  or  to set the correct day.

Set Calendar

NOTE: The calendar only needs to be set when selecting Odd/Even day watering in areas where water restrictions may require this feature.



Press  button until the year, month and day are shown. The “year” will be flashing. Use  or  to adjust if required.



Press  and the “month” will flash. Use  or  to adjust if required.

Press  and the “day” will flash. Use  or  to adjust if required.

HINT: To return to the clock, press  and  together or turn dial to another position.

Before proceeding, ensure the spare watering planner has been completed. From your planner, you should be aware which stations (valves) are allocated to each program. Set one program at a time to ensure that the schedules are completed correctly.



PROGRAMMING


Example: SET PROGRAM 1

Step 1 – SET START TIMES

NOTE: all stations will come on in sequential order for each start time.

Turn the dial to “Set Start Times” and ensure that “Prog No 1” is showing. If not, then use the **P** button to select “Prog No 1”.

The “Start No” will be flashing. The display will show:



Use **+** or **-** to change the “Start No” if required, otherwise press **▶** and the “hour” will flash. Use **+** or **-** to adjust if required.


NOTE: Ensure AM/PM position is correct.

Press **▶** and the “minutes” will flash. Use **+** or **-** to adjust if required.

Each program has up to 4 start times. Should you require a second start time, press **▶** and ‘Start1’ will flash.

Advance to “Start2” by pressing **+**

The display will show:



Press **▶** and proceed as per setting Start 1.

HINT: To toggle a start on or off press **+** or **-** when the hour is flashing. To change to a different program either to review or alter, press the **P** button. Every press will increment to the next program.

PROGRAMMING

Step 2 – SET WATERING DAYS

This unit has interval watering from every day to every 15th day, individual day selection or a 365 day calendar with odd/even day selection in areas where water restrictions require this feature.

INDIVIDUAL DAY SELECTION

Turn the dial to “Set Watering days” and ensure that “Prog No 1” is showing. If not, then use the **P** button to select “Prog No 1”.

“Monday” will be flashing. The display will show:

This refers to Mon being Day1.



To turn Monday off press the **-** button. To turn it back on press the **+** button. To advance to the next day and set it use the **▶** button, the display will then flash Tue and Day 2. Use **+** or **-** to turn days ON or OFF and advance to the next day using **▶**. Remember to set all 7 days ON or OFF.

ODD/EVEN DAY SELECTION (Optional)

In some regions users are only allowed to water their landscapes on **odd** dates if their house number is **odd**, or **even** dates when their house number is **even**.

This controller allows this to be done simply by setting the relevant selection of odd or even and setting the current date into the controller. The controller will account for leap years.

If you require the odd/even day option, simply press the **▶** button until “Odd” is shown. Press the **▶** button and “Even” will be shown.

This feature may be required in areas where water restrictions are enforced.

NOTE: Remember to set the 365 day calendar when setting the clock, or this feature will be out of sequence (refer page 8 “set calendar”).


PROGRAMMING

INTERVAL DAY SELECTION

Press the  button until the “interval days” is flashing. The display will show:

“Interval 1” will be flashing. This means the controller will water every day. The display will show how many days are left before an active schedule.

For example, if it showed “1” then in one day’s time the controller will run this program. To change the interval day, press the  or  button. Select from 1 to 15 interval days.




NOTE: When changing the interval day, the next active day is always changed to 1. This means that tomorrow is the first active day to run.

Step 3 – STATION RUN TIMES

This is the length of time that each station (valve) is scheduled to water on a particular program. Maximum watering time is 12 hours 59 minutes for each station. A station can be assigned to any or all of the possible 3 programs, if required. Turn the dial to the “Set Station Run Times” position.

The display will show:



NOTE: This means that station 1 of program 1 has no run time programmed in it. The controller has permanent memory so when the device is first used there will be no run times set. Unlike other controllers, when there is a power failure, even if the battery is not installed, the programmed values will be restored to the unit.

PROGRAMMING

Step 3 - Station Run Times (cont.)

Press  or  button to select the station (valve) number, and press the  button and the run time minutes will flash. Alter by using  or .

Press the  button and the run time hours will flash. Alter by using  or .

Press the  button and the current station will flash. Select the next station to change by using  or  and proceed by pressing  and alter using  or .

Continue until all the stations in Program1 have been set with a run time or if a station(s) is not required to be active in this particular program, ensure that the run time is set to "OFF".

NOTE: To turn a station "OFF" press the  and  at the same time when the station number is flashing or use  to set minutes to 00 when flashing.

This completes the setting up procedure for automatic program 1.

Select from up to 3 programs using the  button for different watering schedules.

On every press of the  button the program number will increment. Once on the desired number, follow the three steps to set an automated program:

1. Set start Times
2. Set Watering Days
3. Set Station Run Times


TIP: Although the controller will run automatic programs with the main dial in any position (with the exception of "OFF"), it is advisable to leave the main dial in the "AUTO RUN" position when not programming or running manual stations or programs.

MANUAL OPERATIONS

Run a Single Station

The maximum run time for a station is 12 hours 59 minutes. To manually run a single station once, turn the dial to the “System Test or Run Single Station” position.

The display will show:



The default run time for a single station is 10 minutes.

Advance to the selected station by pressing  as many

times as required, and adjust the run time with  and .

The controller will start running the selected station and the run time will decrement in the display.


If there is an active pump set for this station, the pump icon will flash once the  button has been pressed, indicating that the pump/master is running. As soon as the single station run time has elapsed, the unit will revert back to automatic mode. This means that if you forget to turn the dial back to the “Run” position, the controller will still run its automatic starts, as scheduled. To turn the station off, change the position of the main dial, to “OFF”.

HINT: If you wish to alter the default value from 10 mins to some other value and set this as the new default time. Turn the dial to “Run Single Station” press the  button. Then alter the run time using the  or  buttons. Once the new default time is set press the  button again, and the new default will now always appear when you select a “manual single station”.

Run a System Test

To manually run a system test turn the dial to the “System Test or Run Single Station” position, press  and  together.

The display will show:



The default run time for a single station is 2 minutes.

If you wish to alter the run time for **this start only**, use

the  and  buttons. Once the correct run time has been entered, turn the station on and make it run by pressing the .

MANUAL OPERATIONS

The controller will start running all stations with the selected run time. The time will decrement in the display and will sequentially move through all stations, running them for the same set period of time. This option is designed so that it is possible to test all sprinklers and valves that make up the irrigation design.

To skip to the next station press the  button. To go back a station press the  button. To stop the system test, change the position of the main dial, to "OFF".

HINT: If you wish to alter the default value from 2 mins to some other value and set this as the new default time, press the  and  together followed by  button. Then alter the run time using the  or  buttons. Once the new default time is set press the  button again, and the new default will now always appear when you select a "manual system test".

Run a Program


To manually run a complete program or to stack multiple programs to run, rotate the dial to "Run Program". The word "OFF" will be flashing.

The display will show:

To enable program 1 to start press the  button.

The icon "OFF" will change to "ON".

This program has now been enabled so that it can be run. To make program 1 run, press the  button.



NOTE: So long as there are run times in program 1 then program 1 will start and water the stations associated with it.



MANUAL OPERATIONS

There may be times when it is desirable to run more than one program manually. The controller allows this to occur using its unique facility of enabling a program, before running it. For example if I wished to run Program 1 and also Program 2, the controller will manage stacking of the programs so they do not overlap.

Enable program 1 by pressing the  button. To select the next program press the  button, the program number will increment to program 2.

Enable program 2 to run by pressing the  button.

NOTE: to disable a program number, press the  button.

Once both programs have been enabled, they can be run by pressing the  button. The controller will now run all programs that have been enabled starting with the highest numbered program. So in this case, program 2 would run and when it has completed its cycle, program 1 would start and run its cycle.

This method can be used to enable any, or all of the available programs on the controller.

NOTE: When running programs in manual mode the “Budget %” will alter the running times of each individual station.



OTHER FEATURES

Stop Watering

To stop an automatic or manual watering schedule, turn the dial to the “OFF” position.

***NOTE:** For automatic watering remember to turn the dial back to the “Auto Run” position, as “OFF” will stop any future watering cycles from occurring.*

Stacking Start Times

Should you accidentally set the same watering start time on more than one program, the controller will “stack” them in sequential order. All programmed start times will be watered from the highest number first.

Automatic Backup

This product is fitted with permanent memory. This allows the controller to hold all stowed values even in the absence of power sources, which means that programmed information will never be lost. Fitting the 9 volt block battery will keep the real time clock running during power outages. However, if the battery is not fitted the real time clock is backed up every 10 minutes to the non volatile memory. This means that when the power returns the clock will be restored to its last known value.

It is recommended that a battery is fitted and it is changed every 12 months.

A low battery icon will light when the battery has a week left to run. When this occurs, replace the battery as soon as possible so that the clock is maintained correctly during power failures.

WIRELESS RAIN GAUGE INTERFACE

Wireless Rain Gauge Interface

This unit will only interface with the K-Rain KR0203 Wireless Rain Gauge and Weather Station. (The KR0203 is available to purchase separately).

The RPS612 does not need any additional parts or wiring to communicate with the KR0203 Wireless Rain Gauge. Simply install the Rain Gauge onto your gutter or open space where it is exposed to Rain.

Pairing the Wireless Devices

The Rain Gauge & Monitor must be as close as possible to the controller for the wireless initialisation

NOTE: Move the Rain Sensor by-pass switch to "ON"



1. Make sure the power is plugged in to the RPS 612.
2. Unscrew the fascia panel of the controller.
3. Hold the "Reset Button" down. (see image to right)

NOTE: The re-set button is located under the terminal cover and at the "rear" of the PCB at the far right hand end.



4. Place 3 x AAA - ALKALINE batteries into the Rain Gauge and close the battery cover, then 2 x AA ALKALINE batteries into the Monitor.
(make sure you place the batteries in the above order to enable the Wireless pairing to connect correctly with the RPS 612 Controller)
5. Once the batteries are installed, release the "Reset Button".
6. You will see 3 lights appear then disappear - then the "Signal OK" light will appear and disappear. (This confirms that the wireless signal has been linked)
7. Replace the fascia panel screws.
8. Lastly connect 1 x 9V - ALKALINE battery to the RPS612 Controller.
(This enables it to hold it's wireless settings in the controllers memory)



WIRELESS RAIN GAUGE INTERFACE

Testing the Wireless Connection and Rain Sensor

1. With the Rain Gauge main casing removed, push both side of the toggle switch 15 times.

This will simulate an amount of rain above the 4mm base setting to activate the “Sensor Wet” function in the RPS 612 Controller.



2. After 30 - 60 seconds the Monitor will show the measurement of simulated rain in mm's and the RPS 612 will show the centre LED (Sensor Wet) flashing continually. The LCD display will show “Sensor Wet”, at this point the controller will stop all watering for 24 hours.



3. The LED will flash for 24 hours before clearing.
4. If you should require automatic watering immediately after the test period, move the “Rain Sensor” by-pass switch to “OFF”.
(The LED will still flash for 24 hours until clearing, but on the LCD screen you will see “Sensor Dry”)



WIRELESS RAIN GAUGE INTERFACE

The controller has 3 LED's to indicate when the rain gauge is working.

GLOSSARY - Top LED: "SIGNAL OK"


Will flash every 30 seconds to indicate that there is a reliable communication link with the rain gauge.

Middle LED: "SENSOR WET"

Will flash continually when the rain gauge is showing WET. In this mode no automatic watering will occur, and the LCD will show "Sensor Wet".

Bottom LED: "SENSOR BATTERY"

Will show a solid LED when the batteries in the rain gauge are flat and need to be replaced. When this happens the rain gauge will not communicate with the controller.




NOTE: *When the batteries in the rain gauge go flat and are replaced, it is important to re-set the controller, to allow the controller and rain gauge to communicate. In this instance it is important to note that when you install the Rain Gauge, ensure it is in a convenient location to access for battery replacement.*

OTHER FEATURES

Setting Individual Stations to Rain ON / OFF

Turn the dial to “Set Auxiliaries” to enable individual stations to set rain sensor “ON” or “OFF”.

The display will show:



If the station is turned “ON” this means that the sensor will control it, should it rain. The default mode is for all stations to be rain sensor “ON”. Should you have a station (valve) that always needs to be watered, e.g. an enclosed green house or plants that are under cover, then the rain sensor can be turned “OFF” for these particular stations. This way when the sensor is wet they will still water. To select a station to turn “OFF”. Press the button, the word “ON” will now be flashing, use the button to change to “OFF”.

***TIP:** To turn the station back “ON” press the button. To advance to the next station use the button and the station number will increment. Do this operation for all stations (valves) on the controller that need to be altered.*

***HINT:** To disable the rain sensor and allow all stations to water regardless of the setting, move the slide switch marked Rain/Sensor to the “OFF” position. The reactivate it slide the switch to the “ON” position.*


Rain Delay (Rain sensor cont...)

Different rain sensors react in different ways. The most common complaint about rain sensors, is that they dry out too quickly, and allow the system to come on within hours of a rain storm. To counter this problem the controller has a “Rain Delay” setting that allows a specific delay time to elapse after the rain switch has dried out before the controller will water again. Turn the dial to the “Set Auxiliaries” position. Then press the button. The rain delay value will now be flashing.

The display will show:

Press the button to alter the rain delay time in increments of 12 hours at a time.

A maximum delay of 240 hours or 10 days can be set.



OTHER FEATURES

Stop All Watering

To stop all watering cycles during winter, turn the dial to the “OFF” position. The display will show “ALL OFF”:

This means that all automatic schedules will not come on, but the programmed information is still retained in the memory and the clock still keeps track of time even though it is no longer being displayed.



To reactivate watering, turn the dial to the “Auto Run” position.

Water Budgeting & Seasonal Adjustment

The automatic station run times can be adjusted by percentage as the seasons change. This will save valuable water as the run times can be adjusted quickly in spring, summer, and autumn to reduce or increase water usage.

Ensure the dial is in the “Auto Run” position.

Press the  button.

The display will show:



This means that the run times are set to 100%, i.e. if station 1 is set to 10 minutes then it will run for 10 minutes. Should however the value change to say 50% then instead of running for 10 minutes station 1 would now run for 50% of 10 minutes, i.e. 5 minutes.


Conversely should the budget value be altered to show 200% then instead of running 10 minutes on station 1, it would run for 20 minutes. The budget calculation is applied to all stations and all run times that are active.

To increase the budget percentage press the , to decrease the budget percentage press the . The percentage value will increment or decrement in multiples of 10%. The maximum value is 200% and the minimum value is 10%.

To return to the clock display press the  button.

Should the budget value no longer be 100% then it will be shown in the clock display, e.g. if we set the budget to 200%

The display will show:





INSTALLATION INSTRUCTIONS

Mounting the Controller

Install the controller near a 240 VAC outlet. Preferably located in a house, garage, or exterior electrical cubicle. For ease of operation, eye level placement is recommended. Ideally, your controller location should not be exposed to rain or areas prone to flooding or heavy water.

INBUILT MODEL:

The inbuilt controller unit is an **outdoor** model and can be exposed to light rain as it is weather proof.

Fasten the controller using the key hole slot positioned externally on the top centre and the additional holes positioned internally under the terminal cover.

Electrical Hook-up

WARNING:

1. All electrical work must be carried out in accordance with these instructions following all applicable local, state and federal codes pertaining to the country of installation.
Failure to do so will void the controller's warranty.
2. Disconnect mains power supply before any maintenance work to the controller or valves is undertaken.
3. **Do not attempt to wire any high voltage items yourself, i.e. pumps and pump contactors or hard wiring the controller power supply to the mains. This is the field of a licensed electrician. Serious injury or death could result from improper hook up. If in doubt consult your regulatory body as to what is required.**

Field Wiring Connections

PREPARATION

1. Prepare wire for hook-up by cutting the wires to the correct length and stripping approximately 0.25 inches (6.0mm) of insulation from the end to be connected to the controller.
2. Ensure terminal block screws are loosened sufficiently to permit easy access for wire ends. Insert stripped wire ends into the clamp aperture and tighten screws. Do not over tighten as this may damage the terminal block.

INSTALLATION INSTRUCTIONS

- A maximum of 0.75 Amps may be supplied by any output. Check the inrush current of your solenoid coils before connecting more than two valves to any one station.


Power Supply Connections

INBUILT TRANSFORMER

It is recommended that the transformer is not connected to a 240 vac supply which is also servicing or supplying motors (i.e. air conditioners, pool pumps, refrigerators). Lighting circuits are suitable as power sources.

This inbuilt transformer model, is suitable for outdoor installation as the housing is weatherproof and UV stabilized. However it is recommended that the unit be installed in an area which is not exposed directly to the weather.

Terminal Block Layout (9 station example)



GLOSSARY

24 VAC	24VAC power supply connection
C	Common wire connection to field wiring
P1	Master valve or pump start output
ST1-ST9	Station(s) (valves) field connections


INSTALLATION INSTRUCTIONS

Pump Start Relay Connection (Water supply by pump system)

This controller does not provide mains power to drive a pump. A pump must be driven via an external relay and contactor setup as detailed below. The controller provides a low voltage signal that actuates the relay which in turn enables the contactor and finally the pump.

HINT: Although the controller has permanent memory and thus a default program will not cause erroneous valve actuation as in some controllers, it is still good practice when using a system where the water supply comes from a pump to connect unused stations on the unit back to the last used station. This in effect, inhibits the chances of the pump ever running against a closed head.

Single Phase Pump Installation




INSTALLATION INSTRUCTIONS

Master Valve Installation (Water supply off mains water)


The purpose of the master valve is to shut off the water supply to the irrigation system when there is a faulty valve or none of the stations are operating correctly. It's used like a back-up valve or fail safe device and is installed at the start of the irrigation system where it is connected to the water supply line.

USE ONLY 1 AMP FUSE M-205



Power Supply Connections

USE ONLY 1 AMP FUSE M-205



INSTALLATION INSTRUCTIONS

Station Valve Installation


Up to three 24 vac solenoid valves can be connected to each station output and wired back to the Common (COM) connector. When using long runs of cables, be aware that voltage drop can play a significant roll, especially when more than one coil is wired to a single station. As a good rule of thumb select your cable as follows:

- 0–50m cable dia 0.5mm
- 50–100m cable dia 1.0 mm
- 100–200m cable dia 1.5mm
- 200–400m cable dia 2.0mm

When you are using multiple valves per station the common wire needs to be much larger as it needs to carry more current. In these circumstances choose a common cable 1 or two sizes larger than required. When making connections in the field, only ever use gel filled or greased filled connectors. Most field failures occur due to poor connections. The better the connection here, and the better the waterproof seal the longer the system will perform without trouble.



USE ONLY 1 AMP FUSE M-205



INSTALLATION INSTRUCTIONS


Pump Protection (System Test)

In some circumstances not all operational stations might be hooked up. For example, if the controller was capable of running 9 stations but there were only 7 field wires and solenoid valves available for connection. This situation can pose a risk to a pump when the system test routine for the controller is initiated.

The system test routine sequences through all available stations on the controller. In the above example this would mean stations 8 through to 9 would become active and would cause the pump to operate against a closed head. This could possibly cause permanent pump, pipe and pressure vessel damage.

It is mandatory if the system test routine is going to be used, that all unused, spare stations, should be linked together and then looped to the last working station with a valve on it.

Using the above example, the connector block should be wired as per the diagram below.





FAULT FINDING GUIDE

SYMPTOM	POSSIBLE CAUSE	SUGGESTION
No display	Faulty transformer or blown fuse	Check fuse, check field wiring, check transformer
Single station not working	Faulty solenoid coil, or break in field wire	Check solenoid coil (a good solenoid coil should read around 33ohms on a multi meter). Test field cable for continuity. Test Common cable for continuity.
Fuse blows	Incorrect wiring or bad connection. Solenoid coil has shorted through	Check solenoid coil (a good solenoid coil should read around 33ohms on a multi meter). Test field cable for continuity. Test Common cable for continuity. Test connections.
No automatic start	Programming error or blown fuse or transformer	If unit works manually then check the programming. If not then check the fuse, wiring and transformer.
Buttons not responding	Short on button or programming not correct	Check instruction book to ensure programming is correct. If buttons still not responding then return panel to supplier or manufacturer.
System coming on at random	Too many start times entered on automatic programs	Check number of start times entered on each program. All stations will run once for every start. If fault persists return panel to supplier.



FAULT FINDING GUIDE

SYMPTOM

POSSIBLE CAUSE

SUGGESTION

More than one station coming on at once

Possible faulty driver triac

Check wiring and swap faulty station wire's on the controller terminal block with known working stations. If the same outputs are still locked on, return panel to supplier or manufacturer.

Pump start chattering

Faulty relay or pump contactor

Electrician to check voltage on relay or contactor.

Display cracked or missing segments

Display damaged during transportation

Return panel to supplier or manufacturer.

Sensor input not working

Sensor enable switch in the OFF position

Slide switch on front panel to the ON position, check programming to make sure sensor is enabled.





ELECTRICAL CHARACTERISTICS

Electrical Outputs

POWER SUPPLY

Mains supply: This unit runs off a 240 volt 50 hertz single phase outlet.

The controller draws 30 watt at 240 VAC.

The internal transformer reduces the 240 VAC to an extra low voltage supply of 24 VAC. The internal transformer is fully compliant with AS/NZS 61558-2-6 and has been independently tested and judged to comply.

ELECTRICAL POWER SUPPLY: Input 24 volts 50/60Hz

ELECTRICAL OUTPUTS: Maximum of 1.0 amp

To solenoid valves:

24 vac 50/60Hz 0.75 amps max

Note: up to 3 valves per station on the inbuilt model

To the master valve/pump start:

24 vac 0.25 amps max

Note: Transformer and fuse capacity must be compatible with output requirements

OVERLOAD PROTECTION:

Standard 20mm M-205 1 amp fast blow glass fuse.

POWER FAILURE:

The controller has permanent memory so the data is always backed up even with the absence of all power, however to maintain the real time clock as current, a 9 volt block battery should be installed. This will keep the clock time for extended periods without mains power.

WIRING:

The output circuits should be installed and protected in accordance with wiring code for your location.



SERVICING THE CONTROLLER

Servicing the Controller

The controller should always be serviced by an authorised agent.

Follow these simple steps to return the unit:

1. Turn the mains power OFF to the controller.

Note: *If the controller is hardwired, a qualified electrician will be required to remove the entire unit depending on the fault.*

“IF NOT HARDWIRED - PROCEED TO 2”

2. Disconnect the 24 VAC leads at the controller 24 VAC terminals on the very left hand side of the terminal block.
3. Clearly mark or identify all valve wires according to the terminals they are connected to, (1–9). This allows you to easily wire them back to the controller, maintaining your valve watering scheme.
4. Disconnect valve wires from the terminal block.
5. a) Remove the complete panel from the controller housing by unscrewing the two screws in the lower corners of the fascia. (both ends of the terminal block)
b) Remove the complete controller from the wall unplugging the lead.
6. Carefully wrap the panel or controller in protective wrapping and pack in a suitable box and return to your service agent or the manufacturer.

Note: *Tampering with the unit will void the warranty.*

7. Replace your controller panel by reversing this procedure.
The controller should always be serviced by an authorised agent.



SPARE WATERING PLANNER

VALVE NUMBER				PROGRAM				PROGRAM				PROGRAM											
1	2	3	4	5	6	7	8	9	10	11	12	1	2	3	4	5	6	7	8	9	10	11	12
START TIME				WATERING INTERVAL				RUN TIME (minutes)				START TIME				WATERING INTERVAL				RUN TIME (minutes)			
1				3				3				3				3				3			
Start Time 1:				Start Time 1:				Start Time 1:				Start Time 1:				Start Time 1:				Start Time 1:			
Start Time 2:				Start Time 2:				Start Time 2:				Start Time 2:				Start Time 2:				Start Time 2:			
Start Time 3:				Start Time 3:				Start Time 3:				Start Time 3:				Start Time 3:				Start Time 3:			
Start Time 4:				Start Time 4:				Start Time 4:				Start Time 4:				Start Time 4:				Start Time 4:			
2				3				3				3				3				3			
Start Time 1:				Start Time 1:				Start Time 1:				Start Time 1:				Start Time 1:				Start Time 1:			
Start Time 2:				Start Time 2:				Start Time 2:				Start Time 2:				Start Time 2:				Start Time 2:			
Start Time 3:				Start Time 3:				Start Time 3:				Start Time 3:				Start Time 3:				Start Time 3:			
Start Time 4:				Start Time 4:				Start Time 4:				Start Time 4:				Start Time 4:				Start Time 4:			
Notes:																							



GUARANTEE

The manufacturer Guarantees to the original purchaser that any product supplied by the manufacturer will be free from defects in materials and workmanship for a period of five years from the date of purchase. Any product found to have defects in material or workmanship within the period of this Guarantee shall be repaired or replaced by the manufacturer **FREE OF CHARGE**.

The guarantor does not guarantee the fitness for a particular purpose of its products and does not make any guarantee, expressed or implied, other than the guarantee contained herein. The guarantor shall not be liable for any loss from use of the product or incidental or consequential damages including damages to other parts of any installation of which this product is part.

The guarantee shall not apply to any equipment which is found to have been improperly installed, set up or used in any way not in accordance with the instructions supplied with this equipment, or to have been modified, repaired or altered in any way without the express written consent of the company. This guarantee shall not apply to any batteries or accessories used in the equipment covered under this guarantee or to any damage which may be caused by such batteries.

If the Controller develops a fault, the product or panel must be returned in adequate packing with:

1. A copy of your original invoice.
2. A description of any fault.

It is the purchasers responsibility to return the controller to the manufacturer or their agent by prepaid freight.



HOLMAN INDUSTRIES
463 Scarborough Beach Road.
Osborne Park.
Western Australia. 6017.
Tel: **61 8 9204 1011** Fax: **61 8 9204 1013**
Web: www.holmanindustries.com.au
Email: sales@holmanindustries.com.au

Copyright 2011 Holman Industries