



Wi-Fi Control with **HOLMAN** Home



Warm White Wi-Fi Garden Light Controller

User Guide

2021

www.holmanindustries.com.au

CONTENTS

Introduction	2
Initial Setup	2
Basic App Information	5
Choosing Scene Display	6
Device Information	7
Troubleshooting	9

i Some screens in this guide may differ slightly depending on your mobile device and **Holman Home** app version

INTRODUCTION


The **CLXW60 Garden Light**  **Wi-Fi Controller** allows anyone with a smartphone and Wi-Fi access to control their garden lights from anywhere on the globe. Connect your **2-Pin Plug + Socket** to your **Wi-Fi Garden Light Controller** to create stunning lighting displays or select from existing scenes to bring your garden to life. Adjust the colour, mood, intensity, brightness and display all from your smartphone. Find out more online at

www.holmanindustries.com.au/warm-white-wifi-garden-light-controller/



1. Download **Holman Home** onto your mobile device via the

 **App Store** or
 **Google Play**




2. Open **Holman Home** on your mobile device

i You may be prompted to allow notifications—**Holman Home** will still work if you choose not to

3. Tap **SIGN UP**




4. Read our Privacy Policy and tap **AGREE** if you wish to proceed




5. Follow the prompts to register a **Holman Home** account with your email address


- i** When entering an email address ensure the country is correct as this may affect your ability to share control of your **Garden Light Controller** with other users
- i** You may be prompted to allow **Holman Home** to access your location. This allows the app to show weather information. **Holman Home** will still work if you choose not to allow this



6. The home screen will appear and you are now able to add devices to **Holman Home** by tapping **ADD DEVICE** or **+**




7. To find the **Garden Light Controller**, tap **GARDEN LIGHTING**



8. Tap the **WARM WHITE GARDEN LIGHTING** icon to search for your **Garden Light Controller**




9. This begins the Wi-Fi pairing process with your **Garden Light Controller**. Follow the prompts on your mobile device to complete the pairing process





BASIC APP INFORMATION

After completing the Wi-Fi pairing process, your **Garden Light Controller** will be available on the **ALL DEVICES** screen.

1. Tap your **Garden Light Controller** for advanced lighting controls
2. Tap  at the bottom of the screen to turn the light on or off




When your garden lights are on it is possible to:


- i. Adjust the brightness by dragging the slider left to right
- ii. Tap **ON/OFF IN** to set a timer for the lights to stay on for a duration
- iii. Tap **SCHEDULE** to set on and off timers for the light




CHOOSING SCENE DISPLAY

1. Tap **SCENE** as shown to open scene options
2. There are four predefined scenes. The selected scene will have the image displayed in the middle of the screen
3. Using **EDIT** it is possible to:
 - i. Change the **SCENE NAME**,
 - ii. change the scene picture by selecting the **SCENE PIC**,
 - iii. change the flash mode by tapping the **COLOUR FLASH MODE**, select **BREATH** to add multiple scene colours
 - iv. add more colours to your scene by tapping the **SCENE COLOUR** and **+** for each new colour,



- v. adjust the brightness and saturation of your scene colour,
- vi. adjust the **COLOUR FLASH** speed by using the  slider

DEVICE INFORMATION

1. Tap  as shown to display Device Information

i From here you will be able to:

2. Change the name, icon and allocate a location on your **Garden Light Controller**

3. Choose **DEVICE INFORMATION** to see the Virtual ID, IP and MAC Address, Device Time Zone and Signal Strength

4. Select **TAP-TO-RUN AND AUTOMATION** for any smart scenarios you have created




5. Tap **ALEXA** or **GOOGLE ASSISTANT** for information on setting up these services

6. Toggle **OFFLINE NOTIFICATION** to be notified when your device has been offline for more than 30 minutes


7. Tap **SHARE DEVICE** to share control of your **Garden Light Controller** with a user outside your home. We recommend using the **HOME MANAGEMENT** function if you wish to share your **Garden Light Controller** with a user who lives in your home

i All users will need to have a **Holman Home** account to be able to share devices

8. Tap **CREATE GROUP** to control multiple **Garden Light Controllers**



9. For support and fault reporting, tap **FAQ & FEEDBACK**
10. Add the device to your **HOME SCREEN** (🍏 iOS only)
11. Tap **CHECK DEVICE NETWORK** to run a test on your Wi-Fi signal
12. Tap **CHECK FOR FIRMWARE UPGRADE** to ensure your *Garden Light Controller* has the latest firmware
13. Tap **REMOVE DEVICE** to remove your *Garden Light Controller* from *Holman Home*
14. Tap **RESTORE FACTORY DEFAULTS** to remove your *Garden Light Controller* from *Holman Home* and clear all settings back to factory defaults



TROUBLESHOOTING

Symptom	Suggestion
<i>CLXW60 Controller cannot connect to Holman Home</i>	<ol style="list-style-type: none"> 1. When adding your <i>CLXW60</i> to <i>Holman Home</i>: 2. Confirm your <i>CLXW60</i> is powered ON 3. Confirm Wi-Fi AP on your <i>CLXW60</i> is flashing RED 4. Confirm both your <i>CLXW60</i> and smartphone are within Wi-Fi range 5. Make sure the network functions of your Wi-Fi router and smartphone are unblocked; firewalls can block certain ports 6. Confirm your Wi-Fi network name (SSID) has been entered correctly, including spaces. Note this is case sensitive 7. Confirm your Wi-Fi network password has been entered correctly 8. Confirm your <i>CLXW60</i> is connected to a 2.4GHz Wi-Fi network (not 5GHz), enable the broadcast and do not allow the Wi-Fi network to be hidden 9. Confirm your Wi-Fi router encryption method is WPA2-PSK and authentication type is AES, or both are set to automatic 10. If the number of connected devices to the Wi-Fi has reached the amount limit (usually 16 or 50 devices), turn off other Wi-Fi devices and configure again 11. If your Wi-Fi router enables the MAC address filter, remove the device from MAC filter list and make sure the Wi-Fi router is allowing your <i>CLXW60</i> to be connected 12. Make sure that the Wi-Fi router has the DHCP service enabled. If it is not enabled, the address will be occupied 13. Your Wi-Fi router may not compatible with your <i>CLXW60</i>. It is recommended that you replace the Wi-Fi router and try again
No LED lights on	No AC power, or a blown fuse or transformer. Check fuse and transformer output. Turn power on
Buttons not responding	Please contact our Customer Service team 1300 176 188 or email support@holmanindustries.com.au




**Thanks for being a
#SMARTGARDENER**



**We really appreciate having you as a customer,
and would like to say thank you for choosing us.**

We recommend registering your new product on our website. This will ensure we have a copy of your purchase and activate an extended warranty. Keep up to date to with relevant product information and special offers available through our newsletter.



**[www.holmanindustries.com.au/
product-registration/](http://www.holmanindustries.com.au/product-registration/)**

Thanks again for choosing Holman

HOLMAN

For the #SMARTGARDENER   